


SME-112 B

SERVICE MANUAL
SELF PROPELLED AERIAL PLATFORM

SR182/ISR602



Applied to Specification A3, A4, A6.

///NACHI
CORPORATION

1152, RYOKE, AGE0, SAITAMA, JAPAN.

INTRODUCTION

This manual describes the correct adjustment and maintenance procedures for SR-182 self propelled aerial platform.

These procedures will ensure the most effective use of the operation features, and will ensure satisfaction through excellent performance.

Read this manual carefully, and ensure you understand each descriptions correctly.

When carrying out any maintenance or repair work, please carefully note the following.

- ★Use only the spare parts approved by the manufacturer, particularly for load-supporting and safety-related components.
- ★Do not carry out any modification to the machine without obtaining the manufacturer's approval.

Please note that the numerical values in this manual may be subject to change due to engineering improvement.

ELECTRIC SECTION

| | |
|---|------|
| UPPER CONTROL BOX..... | 4-2 |
| Electric circuit..... | 4-3 |
| LEVER POTENTIOMETER..... | 4-4 |
| RELAY BOARD..... | 4-5 |
| LOWER CONTROL BOX..... | 4-6 |
| Electric circuit..... | 4-7 |
| MAIN KEY SWITCH..... | 4-8 |
| VALVE CONTROL UNIT..... | 4-9 |
| 1. External view..... | 4-10 |
| 2. Trimmers and their functions..... | 4-11 |
| 3. LEDs and their functions..... | 4-12 |
| 4. Note on function (NO. 1)..... | 4-13 |
| 5. Note on function (NO. 2)..... | 4-14 |
| INTERFACE BOARD..... | 4-15 |
| Electric circuit..... | 4-16 |
| ACCELERATOR MOTOR..... | 4-17 |
| 1. Electric circuit..... | 4-18 |
| 2. Inspection..... | 4-18 |
| SLOPE SENSOR..... | 4-19 |
| FOOT SWITCH..... | 4-20 |
| ELECTRIC COMPONENTS attached on ENGINE..... | 4-21 |
| 1. Engine stop solenoid..... | 4-21 |
| 2. Glow indicator..... | 4-21 |
| 3. Starter motor..... | 4-22 |
| 4. Safety relay..... | 4-23 |
| 5. Alternator..... | 4-24 |
| 6. Battery relay..... | 4-25 |

ELECTRIC CIRCUIT FOR INDIVIDUAL SYSTEM

| | |
|---|------|
| ENGINE CONTROL SYSTEM..... | 5-2 |
| ROTATION SYSTEM..... | 5-3 |
| EXTENSION SYSTEM..... | 5-4 |
| ELEVATION SYSTEM..... | 5-5 |
| TRAVEL (RIGHT) SYSTEM..... | 5-6 |
| TRAVEL (LEFT) SYSTEM..... | 5-7 |
| ACCELERATOR SYSTEM..... | 5-8 |
| PLATFORM SWING, PLATFORM LEVEL SYSTEMS..... | 5-9 |
| SLOPE WARNING, HORN and WORKING LIGHT SYSTEMS..... | 5-10 |
| MOTION ALARM SYSTEM..... | 5-11 |
| EMERGENCY PUMP SYSTEM..... | 5-12 |

ADJUSTMENT SECTION

| | |
|--|------|
| RELIEF VALVE P1 and P4..... | 6-2 |
| RELIEF VALVE P2..... | 6-3 |
| RELIEF VALVE P3..... | 6-4 |
| OPERATIONAL SPEED..... | 6-5 |
| 1. Measurement procedures of "Maximum operational speed"..... | 6-5 |
| 2. Specific "Maximum operational speed"..... | 6-6 |
| 3. Adjustment procedures of "Operational speed"..... | 6-7 |
| TRIMMER'S IDENTIFICATION ON "VALVE CONTROL UNIT"..... | 6-14 |
| ADJUSTMENT DATA SHEET..... | 6-15 |

APPENDIX

| | |
|---|------|
| TROUBLE SHOOTING..... | 7-2 |
| Identifications of | |
| "Control devices" and "Fuses"..... | 7-4 |
| HYDRAULIC CIRCUIT DIAGRAM..... | 7-5 |
| IDENTIFICATIONS OF HYDRAULIC COMPONENTS.. | 7-6 |
| ELECTRIC CIRCUIT DIAGRAM..... | 7-7 |
| IDENTIFICATIONS OF ELECTRIC COMPONENTS.. | 7-8 |
| ELECTRIC WIRE HARNESS..... | 7-9 |
| ELECTRIC WIRING CHART..... | 7-10 |
| TIGHTENING TORQUE STANDARD..... | 7-10 |

INSPECTION MANUAL (for SP, SR series)




| | |
|--|------|
| PROCEDURES OF DAILY INSPECTION..... | 8-1 |
| DAILY INSPECTION CHECK SHEET..... | 8-3 |
| PROCEDURES OF PERIODICAL INSPECTION..... | 8-5 |
| PROCEDURE OF FUNCTION TEST..... | 8-11 |
| PERIODICAL INSPECTION CHECK SHEET..... | 8-12 |

1
GENERAL INFORMATION

OVERALL DIMENSION (for Version: A3)




(600-09386)

Crawler : Komatsu PC100-5



OVERALL DIMENSION (for Version: A4 A6) (600-09428)

Crawler : Komatsu PC100-6




SPECIFICATIONS

| Model | | SR-182 | ISR-602 | | |
|---|------------------------------|--|---|-----------------------|-------------------------|
| Weight | Overall weight | 13,500 kgf | 29,760 lbs | | |
| | Max. ground contact pressure | 0.78 kgf/cm ² | 11 psi | | |
| Engine | Model | ISUZU 4BD1-PE03 | ← | | |
| | Total displacement | 3,856 cc | 235 in ³ | | |
| | Output power | 69.5 ps / 2,200 rpm | 68.5 HP / 2,200 rpm | | |
| | Output torque | 24.0 kgf-m/1,600 rpm | 174 ft-lb / 1,600 rpm | | |
| Engine (From serial No. 661665 and after) | Model | A-4BG1-PE05 | ← | | |
| | Total displacement | 4,329 cc | 264 in ³ | | |
| | Output power | 84 ps/2,200 rpm | 61.8 kw/2,200 rpm | | |
| | Output torque | 28.0 kgf-m/1,600 rpm | 203 ft-lb / 1,600 rpm | | |
| | Engine oil capacity | 13 liters | 3.43 gals | | |
| | Cooling water capacity | 16,5 liters | 4.36 gals | | |
| | Fuel tank capacity | 230 liters | 60.8 gals | | |
| | Engine speed | 1,200~2,300 rpm | ← | | |
| | Battery | DC 12v / 70 AH×2 | ← | | |
| Platform | Rated load | 250 kgf or 2 persons + Tools (90 kgf) | 550 lbs or 2 persons + Tools (200 lbs) | | |
| | Max. allowable side force | 41 kgf (400N) | 90 lbs | | |
| | Inner dimensions | 1,800×750×1,120 mm | 5'11"×2'6"×3 ft 8 in | | |
| | Rotation angle | 180° | ← | | |
| | Maximum floor height | 18.0 meters | 59 feet | | |
| | Maximum working radius | 16.5 meters | 54 ft 2 in | | |
| Boom | Boom length | 7.19~16.86 meters | 23 ft 7 in ~ 55 ft 4 in | | |
| | Boom angle | -20~70 degrees | ← | | |
| | Rotation angle | 360° continuously | ← | | |
| Operational speed | Elevation | UP | 70±5 seconds / stroke | 50±5 seconds / stroke | |
| | | DOWN | 70±5 seconds / stroke | 55±5 seconds / stroke | |
| | Extension | OUT | 35±5 seconds / stroke | ← | |
| | | IN | 30±5 seconds / stroke | ← | |
| | Rotation | C. W. | 150±10 seconds / 1 turn | 70±5 seconds / 1 turn | |
| | | C. C. W. | 150±10 seconds / 1 turn | 70±5 seconds / 1 turn | |
| | Travelling | High speed | Forward | 32±4 seconds / 10 m | 29±3 seconds / 10 yards |
| | | | Reverse | 32±4 seconds / 10 m | 29±3 seconds / 10 yards |
| | | Low speed | Forward | 51±8 seconds / 10 m | 47±7 seconds / 10 yards |
| | | | Reverse | 51±8 seconds / 10 m | 47±7 seconds / 10 yards |
| | Platform rotation | Right | 20±4 seconds / stroke | ← | |
| Left | | 20±4 seconds / stroke | ← | | |

| | | | | |
|-------------------------|----------------|--|---|--|
| Hydraulic system | Hydraulic oil | Tank capacity | 250 liters | 66 gallons |
| | | Recommended oil | Shell Tellus oil 32 | ← |
| | Hydraulic pump | Type | Gear pump (Double) | ← |
| | | Discharge volume | 30.2 + 30.2 cc/rev. | 1.84 + 1.84 in ³ / rev |
| | | Pump speed | 1,200~2,300 rpm | ← |
| | Rated pressure | Main system (Elevation, Extension Rotation & Travelling) | 210 \pm ₀ ⁵ kgf/cm ² | 3,000 \pm ₀ ⁷⁰ psi |
| | | Sub system (Platform rotation) | 140 \pm ₀ ⁵ kgf/cm ² | 2,000 \pm ₀ ⁷⁰ psi |
| Maximum allowable slope | | | 5 degrees | ← |
| Gradeability | | | 27 degrees (51 %) | ← |

WORKING RANGE CHART




2
MECHANICAL SECTION

BOOM

The boom Assy consists of 1st boom, 2nd boom, 3rd boom, extension cylinder, extension/retraction wire ropes, hydraulic plumbings, electric cables and their sheaves.




The 2nd boom is extended or retracted by the Extension cylinder directly. However, the 3rd boom is telescoped by the movement of 2nd boom through extension/retraction wire ropes.

Fig:1



- | | |
|--------------------------------|---|
| 1. 1st boom. | 10. Set pin A. (for Extension cylinder) |
| 2. 2nd boom. | 11. Set pin B. (for Extension cylinder) |
| 3. 3rd boom. | 12. Extension cylinder. |
| 4. Extension wire rope. | 13. Set pin. (for Roller) |
| 5. Retraction wire rope. | 14. Slider. |
| 6. Lock-nut & Adjust-nut NO.1. | 15. Slider. |
| 7. Lock-nut & Adjust-nut NO.2. | 16. Slider. |
| 8. Sheave A. | |
| 9. Sheave B. | |

1. Sectional drawings



2 . Inspection procedures

The boom is to be disassembled for a detailed inspection every 4 years.

1. Clearance between each boom section.

1) Check the clearance between each slider and boom section.

* Specific clearance : 2.0mm or less. (0.08" or less)

2) If the clearance is not adequate, adjust the clearance by adding or reducing the spacers installed under the each slider or by adjusting the screws.

NOTE:

* Check each slider for wear, and replace if necessary.

* Apply a thread lock agent to the thread of each set screw for sliders before setting.

Recommended thread lock agent : 3 Bond. 1374.

2. Bend of boom


1) Set the boom horizontally and extend it fully.

2) Visually check the bend of each boom.

3) If the bend seems to be excessive, stretch a thread over the boom and measure the bend accurately as shown in the figure below.

NOTE: If the bend measured exceeds the serviceable limit (9.5mm, 0.37"), replace the boom.

Fig:2



3. Dents, scratches.

Check the each boom for both dents and scratches thoroughly.

If any dent or scratch which exceeds the serviceable limit

(Length : 50mm or more, Depth : 2mm or more) exists, replace the boom.
(1.97") (0.08")

4. Cracks.

Check each boom thoroughly for cracks.

For fine cracks, use "COLOR CHECK" or penetrant check.


* Pay special attention, when checking each pin boss and welded part.

3. Extension/Retraction wire ropes.

After disassembling the boom, inspect extension and retraction wire ropes as follows.

- 1) Measure the diameter of both the extension and retraction wire ropes with slide calipers. Replace the rope if the decrease in the diameter is more than 3% of the nominal diameter.


Fig:3



| | Nominal diameter | Serviceable limit |
|----------------------|----------------------|---------------------------------|
| Retraction wire rope | ϕ 8mm (0.315") | ϕ 7.76mm (0.306") or less |
| Extension wire rope | ϕ 12mm (0.472") | ϕ 11.64mm (0.458") or less |


- 2) Check for broken wires.
If 3 or more wires of a wire rope are broken in a twist stroke, replace the wire rope.

Fig:4



- 4) If any kinks are observed, replace the wire rope.
Also, an extremely deformed wire rope requires replacement.

Fig:6




- 3) Check wire ropes for rust.
If rust is evident around the inside of the wire rope, replace it.

Fig:5



- 5) Carefully check the end sections of a wire rope, especially sections A and B. Replace the wire rope if any defects are found.

Fig:7



4. Tension of extension/retraction wire ropes

Extend/retract the boom for a full stroke, check for any jerky movements caused by loose or stretched extension/retraction wire ropes.

If the wire ropes are loose, adjust their tensions as follows.

- 1) Retract boom fully and set it horizontally.
- 2) Loosen both the lock-nuts and the Adjustment nuts NO.1 ②, which are located on both sides of the top part of the 1st boom.
- 3) Lubricate the Adjustment nuts NO.1 with machine oil, and make sure that the nuts turn smoothly on the threads.
- 4) Tighten both of the Adjustment nuts NO.1. Do this alternately using a torque wrench, until the specified tightening torque is reached.

Specified tightening torque of Adjustment nuts NO.1: 1.0~1.5kgf-m (7.2~10.8ft-lb)

- 5) Check dimension A shown in the figure below, and make sure that it is 420^{+10}_{-0} mm.
(16.5^{+0.4}₋₀")


If the measurement of dimension A is less than 420mm (16.5") :

- Screw out Adjustment nuts NO.1 ② and screw in Adjustment nuts NO.2 ① until the specified dimension A is obtained.

If the measurement of dimension A is more than 430mm (16.9") :

- Screw out Adjustment nuts NO.2 ① and screw in Adjustment nuts NO.1 ② until the specified dimension A is obtained.

- 6) Extend/retract boom several times for a full stroke, and recheck the tightening torque of Adjustment nuts NO.1, and dimension A, then secure the Adjustment nuts with lock-nuts.




Note : Adjust the tension of wire ropes every 6 months.

5. Tension of Electric cable

Apply tension on the each electric cable after adjusting the tension of "Extension/Retraction wire ropes as follows.

It is advisable to apply the tension on each electric cable every 6 months or 600 working hours.

- 1) Position the boom horizontally, retract it fully, and check the tension of the "Extension/Retraction wire ropes."
(Adjust the tension if necessary.)
- 2) Loosen the cable clamps at the top of the 3rd boom.
- 3) Pull each electric cable by applying 30~40kgf, and lock the cable with the cable clamp. (66~88lbs)




Note : Apply tension to the cables every 6 months.

T.T.B. (Turn Table Bearing)

The T.T.B. is mounted between the carrier-frame and the turn-table, it enables the turn-table to rotate freely over the carrier-frame.

Fig:1



1. Inspection procedures.

1. Check anchor bolts and nuts for any looseness, omissions or any other damage.
 - a. Loose bolts should be removed and checked for damaged threads and deformation.
 - b. When resetting anchor bolts or nuts, apply thread lock agent to the threads.
-Recommended thread lock agent : 3 Bond 1374.
 - c. Tighten anchor bolts and nuts to the specified tightening torque.
-Specified tightening torque : 35.9-48.5 kg-m (260~350 ft-lb).

NOTE : Before removing anchor bolts or nuts, use a gas bunner to heat them until they are red hot. This will remove the thread lock agent applied on the thread of each bolt and nut.

2. Check ring gear for cracks, scorings and any other damage.

For any fine cracks, use a penetrant check such as a color check.

3. Check the back-lash between the ring gear of T.T.B. and the drive pinion of Rotation gear box.

-Standard back-lash : 0.6mm (0.024") or less.


NOTE : To measure the value of back-lash, rotate turn-table and crush a lead-wire between the ring gear and the drive pinion, then measure the thickness of the crushed lead-wire.

When the back-lash is not within the the tolerance, adjust it by moving the position of rotation gear box.

4. Check the free-play between inner and outer races of T.T.B..

To check the free-play, use the following steps.

Fig:2



- a. Set a dial gauge between the turn-table and the carrier-frame, as shown in Fig : 2.
- b. Retract and raise the boom fully (with minimum boom length and maximum boom angle), and set the pointer of the dial gauge at "ZERO".
- c. Lower the boom, set it horizontally and extend it fully, then re-check the dial gauge.

The reading of the dial gauge is the value of free-play.


-Standard free-play : 0.9mm (0.035").

-Limit of free-play : 3.0mm (0.118").

NOTE :

The T.T.B. with free-play in excess of the limit 3.0mm (0.118") should be replaced.

PLATFORM SWING MECHANISM



3
HYDRAULIC SECTION

NOTE ON OVERHAULING THE HYDRAULIC SYSTEM

When repairing, servicing or overhauling the hydraulic system, take the following into consideration.

1. When disconnecting plumbing.
 - a. Prepare a suitable container to catch the draining oil.
 - b. Put "MATCH MARKS" on each part before disconnecting. This will make recognition on the time of reconnection easier.
 - c. Use double spanners as not to damage the plumbing and components.
 - d. Clean the plumbing or components out before disconnection, to prevent foreign particles from entering into the hydraulic system.
 - e. Install proper plugs to the disconnected plumbing or components, to prevent foreign particles from entering into the hydraulic system.
2. When connecting the plumbing.
 - a. Check the "MATCH MARKS" made on disconnection to avoid incorrect connections.
 - b. Clean the connecting plumbing, to prevent foreign particles from entering into the hydraulic system.
 - c. When connecting the TP adaptors, wind seal-tape at least one and a half times around the threads.
 - d. Use double spanners when tightening the connectors.
3. When assembling or disassembling hydraulic components.
 - a. Put proper plugs onto the openings of oil passages to prevent foreign particles entering into the components.
 - b. Before disassembling, clean the component thoroughly with a solvent and compressed air.
 - c. Clean each disassembled part with solvent thoroughly. This will ensure easier check-up procedures, and prevent the introduction of foreign particles.
 - d. When assembling O rings or packings, apply a little grease or lubricate them with hydraulic oil.
 - e. When installing taper plugs, wind seal-tape at least one and a half times around the threads.

HYDRAULIC OIL

It should be noted that hydraulic system failures are often caused by defective hydraulic oil which in turn is caused by improper maintenance.

To insure maximum utilization, the followings should be observed.

- 1) Oil temperature should be below 70°C and ideally below 60°C (140°F), as heat causes earlier oxidation.
On the other hand when the oil is very cold, a warm-up period is recommended before operation.
- 2) Regularly check for contaminants in the hydraulic oil.
Contaminants in the oil may speed up the oxidation process.
- 3) Avoid introduction of water into the hydraulic system, as water will cause additives to deteriorate and if the amount of water is sufficiently large, it will cause the oil to emulsify.
- 4) As a rule, do not mix oils from different manufacturers.
Furthermore, do not mix oils of the same make if they have different product names or viscosity differences.
Improper mixing will cause the additives to deteriorate.
- 5) Eliminate oil leakage as much as possible from the hydraulic component and its plumbings.
- 6) Make it a habit to check the oil regularly.

Guidelines for oil change.

An oil change should be carried out every 1,200 working hours or on an annual basis.

(For new Machine : After 300 working hours or 3 months use.)

In the meantime, take a small amount of oil from the oil reservoir, and conduct the following inspections and tests.

- 1) Visually compare the sample taken from the oil reservoir, and a fresh, unused sample.
- Color -
As the oil deteriorates, the color becomes darker and less clear.
If the oil is milky, let it settle for about 10 hours, then observe.
 - a) If there is little or no change to the milky oil, the cause is water mixed into the oil.
In this case a complete oil-change is necessary.

- b) If the oil and water separate, this indicates that the water has been introduced to the hydraulic system a short time ago. It can be reused after taking out water.
- c) If the oil becomes clear with no water at the bottom of the container, it is an indication that air has been mixed into the oil.
 - Access the cause of the air.

- Smell -

If the oil has a strong pungent odor, it is an indication that the deterioration has progressed to a point where an oil-change is needed.

- Contaminants -

If suspended contaminants are introduced to the hydraulic oil, leave the sample for 1 to 2 days and gather sediments for further tests of the development of contaminants.

2) Analytical tests.

Test the hydraulic oil for viscosity, water content, oxidation, contaminants, etc.

| <u>Test for</u> | <u>Shell Tellus 32</u> | <u>Shell Tellus T15</u> |
|------------------------------|------------------------|-------------------------|
| Contamination | Within NAS Class 12. | |
| Water content (%) | Less than 0.5%. | |
| Oxidation (mgKOH/g) | 0.4mgKOH/g. | |
| Viscosity (cst) (at 40°C) | 32 cst. | 15 cst. |

Suction strainer.

Be sure to clean suction strainer at the time of an oil change.

Wash and clean the strainer in kerosene or a similar solvent, then air-blast it from the inside.

Oil filters.

Regularly replace the filter element. If the machine is new, replace the element after 300 working hours or 3 months use.

Thereafter, replace it every 1,200 working hours or on an annual basis.


(The element should also be replaced at the time of an oil change.)

OIL RESERVOIR

The oil reservoir consists of such components as shown in the figure below, and supplies hydraulic oil to the whole hydraulic system.

Capacity 250 liters (66 gals)

Recommended oil Shell Tellus oil 32



Oil change interval

- Every 1,200 hours or annually
- For a new machine, the first oil change should be carried out after 300 hours or 3 months use.

Note

- When checking oil level, retract and lower the boom fully.
- Clean "Suction strainer" and replace "In-line filter", when changing the hydraulic oil.


IN-LINE FILTER

The in-line filter is installed at the outlet line of the hydraulic pump to eliminate the contaminants contained in the hydraulic oil.

Replacement interval : Every 1,200 working hours or annually.

(of filter element)


NOTE : The first replacement of the filter element for new machine should be carried out after 300 working hours or 3 months use.



HYDRAULIC PUMP

The pump is driven by engine directly, and supplies pressurized oil to hydraulic system

| | |
|--------------------------|--|
| Type | Gear pump (Double) |
| Discharge volume | 30.2 + 30.2cc/rev (1.84+1.84 in ³ /rev) |
| Rated pressure | 210kgf/cm ² (3,000 PSI) |
| Rotating direction | Clock wise |



MAIN CONTROL VALVE NO.1 and NO.2

The main control valve is a "Solenoid Operated Proportional Type" and controls the following hydraulic systems.

1. Elevation system.
2. Extension system.
3. Rotation system.
4. Travel system.

When the main control valve is operated by the control levers (or Potentio meters) located at upper control box, the main spools of the valve are shifted proportionally in accordance with the operated value of the control levers.

Thus, the flow which is supplied to the each hydraulic actuator is controlled proportionally.

On the other hand, when the main control valve is operated by the control switches located at the lower control box, the valve is operated as a conventional solenoid valve.

* Rated pressure.

at P, A, B ports : 250 kg/cm². (3,555 PSI)


at T port : 10 kg/cm². (140 PSI)

* Solenoid.

Rated voltage : DC 24 V


Rated current : 650 mA

Resistance : 30 Ω




1. Illustrations



Main control valve NO.1(302-05214)




Main control valve NO.2(302-05213)





2. Sectional drawings




Detail of port relief V




A - A section



Detail of pilot valve



B - B section






Detail of Main relief V

3. Trouble shooting

| Trouble | Check point | Result | Cause | Remedy | |
|--|---|--|--|---|-------------------------------------|
| Inoperative actuator or Operational speed of the actuator is too slow. | Check the "GAIN voltage" at "Valve control unit". | No "GAIN voltage" is obtained. | Defective "Potentio meter" or "Control switch". | Replace the "Potentio meter" or "Control switch". | |
| | | | Inadequate adjustment of "GAIN voltage". | Readjust the "GAIN voltage" at the "Valve control unit". | |
| | | | Defective "Valve control unit". | Replace the "Valve control unit". | |
| | | | Defective electric wirings. | Repair the electric wirings. | |
| | | "GAIN voltage" is too low. | Battery voltage is too low. | Charge or replace the battery. | |
| | | | Inadequate adjustment of "GAIN voltage". | Readjust the "GAIN voltage" at the "Valve control unit". | |
| | | | Actuator is operative. | Defective solenoid. | Replace the solenoid. |
| | | | | Sticked "Piston" in "Pilot valve" installed under the "Solenoid". | Clean or replace the "Pilot valve". |
| | Actuator is not operative. | Sticked "Main spool" or "Valves" caused by contaminated hydraulic oil. | Clean the hydraulic system, and replace the hydraulic oil. | | |
| | | | "PC valve" is stucked and the unloading pressure is not obtained. | Clean or replace the "PC valve". | |
| | | Sticked "Pilot valve" installed under the "Solenoid". | Clean or replace the "Pilot valve". | | |
| | | Sticked "Main spool". | Clean or replace the "Main control valve Assy". | | |
| | | Sticked "Sectional PC valve". | Clean or replace the "Sectional PC valve". | | |
| | | Defective "Springs". | Replace the "Springs". | | |
| Clogged "Orifice". | | Clean or replace the "Orifice". | | | |
| Distorted "Valve body" caused by improper mounting. | | Remount or replace the "Main control valve". | | | |
| Operational speed is too fast, when operating control lever slightly. | Check the "NULL voltage" at "Valve control unit". | "NULL voltage" is too high. | Inadequate adjustment of "NULL voltage". | Readjust the "NULL voltage" at the "Valve control unit". | |
| Actuator haunts, after overhauling hydraulic system. | | | Air is in the hydraulic system. | Bleed air by operating actuator several times". | |
| | | | Loosen the "Air bleed screw" installed on "Solenoid", and bleed air. | | |
| Actuator is powerless. | Check the "MAX. pressure". | "MAX. pressure" is too low. | Improper adjustment of "Relief valve". | Readjust the "Relief valve". | |
| | | | "PC valve" is loose. | Tighten the "PC valve". | |
| Erratic hydraulic pressure, or higher pressure is not achieved. | Disassemble the "Relief & PC valves". | | Defective spring. | Replace the spring. | |
| | | | Worn out "Poppet" or "Poppet seat". | Replace the "Relief" or "PC valve". | |
| | | | Sticked "Plunger". | Clean or replace the "Relief" or "PC valve". | |

PLATFORM SWING SOLENOID VALVE

The valve is operated by a solenoid, and is controlled electrically by the platform swing switch located on the upper control box.




PRIORITY VALVE

The priority valve maintains the flow which comes out of the "PF port" at the constant level, regardless of any variation to the volume of pump discharge. While the rest of the pump discharge volume is by-passed through the "EF port". The relief valve incorporated in the valve is for limiting the maximum hydraulic pressure for the "PF port".

For SR-182, the flow and the maximum hydraulic pressure of the Platform swing system are both limited by the priority valve. This is because the system is supplied with hydraulic power through the "PF port".

- * Rated pressure : 140 kg/cm². (2,000 PSI)
- * Constant flow : 8 liters/min. (2.1 gals/min)
(at PF port)
- * Relief valves (P3)
Adjustable pressure range : 90~140 kg/cm². (1,280~2,000 PSI)
Pre-set pressure : 140 kg/cm². (2,000 PSI)



NOTE : Refer to ADJUSTMENT SECTION to adjust the Relief valve.

SWIVEL JOINT

The swivel joint is installed at the rotation center of the turntable to supply pressurized oil to the "Travel motors".

Fig:1






Fig:2



Disassembly

1. Remove snap ring ④ and spacer ③.
2. Press out the shaft ② from the case ① using a hydraulic press.
(or pull the shaft ② out of the case ① using gear puller as shown in Fig:3.)

Fig:3



3. Remove the spacer ⑥ from the shaft.
4. Remove all of the O rings from the shaft.

Inspection

1. Check case ① and shaft ② for excessive wear, cracks, scorings, and any other damage.
2. Check the clearance between case ① and shaft ②.
-If the clearance exceeds the limit, replace the shaft or the case.
Limit of clearance : 0.4mm (0.016").
3. Check each groove on case ① and shaft ② for ridges, and sharp edges.
-Ridges and sharp edges should be removed before installing O rings, as such faults may cause damage to the O rings.

Assembly

Assemble in the reverse order of disassembly, paying particular attention to the following points.

- Do not reuse O rings.
- Apply a slight amount of grease to O rings before installation.

ROTATION MOTOR UNIT

The unit consists of such major components as "Hydraulic motor" "Brake valve" and "Reduction gear box" as shown in the figure below.

Hydraulic pump



- Type ----- Orbit type
- Discharge volume ----- 195cc/rev (11.9 in³/rev)

Brake valve


- Preset pressure ----- 60kgf/cm² (850 PSI)

Reduction gear box

- Type ----- Planetary gear
- Reduction ratio ----- 1/16.6
- Gear oil ----- Shell Omala oil 460 (1.1 liters, 0.3 gals)




ELEVATION CYLINDER



Tightening torque
72 ~ 88 kgf-m
(520 ~ 635 ft-lb)


Tightening torque
350 ~ 380 kgf-m
(2,530 ~ 2,750 ft-lb)



| | | | | | |
|---|----------------|----|--------------|----|----------------------|
| 1 | Cylinder tube | 9 | O ring | 17 | O ring |
| 2 | Piston rod | 10 | Backup ring | 18 | Spherical bushing |
| 3 | Cylinder head | 11 | U ring | 19 | Self-lock nut |
| 4 | Piston | 12 | U ring | 20 | Grease fitting |
| 5 | Cushion collar | 13 | Cushion ring | 21 | Grease fitting |
| 6 | Bushing | 14 | Snap ring | 22 | Single holding valve |
| 7 | Bushing | 15 | O ring | 23 | Bolt |
| 8 | Dust seal | 16 | O ring | 24 | Spring washer |

ELEVATION CYLINDER

With Emergency descent handle.



| NO. | Description |
|-----|----------------------|
| 1 | Cylinder tube |
| 2 | Piston rod |
| 3 | Cylinder head |
| 4 | Piston |
| 5 | Cushion collar |
| 6 | Bushing |
| 7 | Bushing |
| 8 | Dust seal |
| 9 | Back-up ring |
| 10 | U-ring |
| 11 | U-ring |
| 12 | Cushion ring |
| 13 | Snap ring |
| 14 | O-ring (G-160) |
| 15 | O-ring (P-150) |
| 16 | O-ring (G-50) |
| 17 | Spherical bearing |
| 18 | Self-lock nut |
| 19 | Grease fitting |
| 20 | Grease fitting |
| 21 | Bolt |
| 22 | Spring washer |
| 23 | |
| 24 | Single holding valve |
| 25 | O-ring (P-15) |
| 26 | Bolt |
| 27 | Pipe |
| 28 | Pipe |
| 29 | Connector |
| 30 | Connector |

SINGLE HOLDING VALVE (for Elevation cylinder)




The "Single holding valve" is mounted on the "Elevation cylinder" to prevent "Natural descent" of the cylinder caused by the gravities of boom and platform.

NOTE: "Natural descent" of cylinder.

The phenomenon that the hydraulic cylinder is extended or retracted due to the external force exerted.

Rated pressure : 210 kg/cm². (3,000 PSI)

Rated flow : 80 liters/min. (21.1 gals/min)



SINGLE HOLDING VALVE (for Elevation cylinder)



With Emergency descent handle

The Single holding valve is mounted on the Elevation cylinder to prevent any "Natural descent" of the cylinder caused by the gravities of the boom and the platform.

NOTE : Natural descent

This phenomenon causes the hydraulic cylinder to be extended or retracted due to external forces.

*To open the valve manually, turn this handle clockwise untill it stops.
To close the valve, turn this handle counter-clockwise untill it stops.
(Emergency descent handle)*




Inspection procedures

1. Check the external oil leakage thoroughly.
2. Check the internal oil leakage, using the following steps.
(Internal oil leakage can be inspected by checking the "Natural descent" of the elevation cylinder.)
 - 1) Park the machine on an area of firm level ground.
 - 2) Start the machine, and position the boom, so that the boom angle is set at around 45degrees.
 - 3) Stop the engine, then put a mark on the piston rod of elevation cylinder as shown in Fig: 2.

Caution : Take care when marking the piston rod so as not to damage it.

Fig:2




- 4) After marking the rod, measure the dimension A (as shown in Fig : 2), then leave it for 10 minutes.
- 5) After 10 minutes, measure the dimension A' between the mark made in step 3 and the edge of cylinder tube as shown in Fig : 2.
A—A'=Natural descent of elevation cylinder.
Serviceable limit.....2mm/10minutes. (0.08"/10min)
- 6) If the "Natural descent" exceeds the limit (2mm/10min), check the single holding valve and the elevation cylinder for internal oil leakage.

NOTE : To indentify which has internal oil leakage (the single holding valve or the elevation cylinder), refer to the following steps.

- 1) Under the condition that the elevation cylinder is loaded with the gravities of boom and platform, disconnect the hydraulic hose connected to port—A at the single holding valve.
- 2) If hydraulic oil drips continuously from port—A of the single holding valve, this indicates internal oil leakage from the single holding valve.
However, if the oil-drips stop after a while, this indicates that elevation cylinder has internal oil leakage.

Caution : Before disconnecting the hydraulic hose, make sure to support the boom using such as crane to prevent the boom from unexpected descent.

EXTENSION CYLINDER





| | |
|----|----------------------|
| 1 | Cylinder tube |
| 2 | Piston rod |
| 3 | Cylinder head |
| 4 | Bushing |
| 5 | U ring |
| 6 | Back-up ring |
| 7 | Dust seal |
| 8 | O ring |
| 9 | O ring |
| 10 | Lock plate |
| 11 | Spacer |
| 12 | Piston |
| 13 | U ring |
| 14 | Back-up ring |
| 15 | Wear ring |
| 16 | O ring |
| 17 | Back-up ring |
| 18 | Set screw |
| 19 | Double holding valve |
| 20 | Bolt |
| 21 | Spring washer |

DOUBLE HOLDING VALVE for Extension cylinder

The double holding valve is mounted on the Extension cylinder, since the cylinder tends to extend or retract due to the gravities of boom and platform.


Fig:1



Inspection procedures

1. Check the external oil leakage thoroughly.
2. Check the internal oil leakage, using the following steps.
(Internal oil leakage is inspected by checking the "Natural descent" of the Extension cylinder.)
 - 1) Park the machine on an area of firm level ground.
 - 2) Extend the boom by about 1 meter, and raise it fully.
 - 3) Stop the engine, and put a mark on the 2nd boom as shown in fig : 2 below.

Fig:2




- 4) Measure the Dimension B as shown in Fig : 2 above.
then, leave it for 10 minutes.
- 5) After 10 minutes, measure the Dimension B' as shown in Fig : 2.
 - * $B - B' = \text{Natural descent of extension cylinder.}$
 - * Serviceable limit.....2mm/10min. (0.08"/10min)
- 6) If the "Natural descent" exceeds the Serviceable limit, further check the internal oil leakage of the Double holding valve or Extension cylinder by referring to the clause of SINGLE HOLDING VALVE. (for Elevation cylinder)

PLATFORM LEVELLING SYSTEM

The system maintains the platform at its level position automatically, regardless of boom's vertical movements.

It consists of Upper, and lower levelling cylinders, Double pilot check valve, Platform level solenoid valve, and Combination valve as shown in the figure below.

Fig:1



1. Note on function

Two levelling cylinders are in place, as shown in Fig : 1.

When the boom is lowered, the Lower levelling cylinder is retracted and the hydraulic oil in the bottom room of the cylinder flows into the bottom room of Upper levelling cylinder.

The sizes of the both levelling cylinders are exactly same.

Therefore, the Upper levelling cylinder extends simultaneously with the retraction of the Lower levelling cylinder.

Thus, the platform is balanced by the "Levelling cylinders" to maintain its level, as the boom is lowered.

When the boom is raised, the levelling cylinders work in an exactly opposite fashion to that described above.

2. Inspection procedures

1. Tilt of platform.

Perform elevation and extension operations several times, and check that the platform always stays level.

If the platform does not stay level, check the levelling system as follows.

- 1) Thoroughly check the system for external oil leakage.
- 2) Bleed air from the platform levelling system. (refer to the "Air bleeding procedures" on the next page.)
- 3) Check the internal oil leakage of the "Combination valve".
Make sure the two stop valves on the combination valve are closed firmly.
- 4) Check the internal oil leakage of the "Double pilot check valve".
- 5) Check the internal oil leakage of the "Upper and Lower levelling cylinders."

2. Natural descent.

Load the platform with its maximum load (250kg), then visually check for any sign of the platform tilting downward. (550lbs)

If the platform descends naturally, thoroughly check the levelling system for external oil leakage, Then check for internal oil leakage in the components listed below.


- Double pilot check valve.
- Combination valve.
- Upper and lower levelling cylinders.

3. Adjustment of Platform level

CAUTION:

- *Do not attempt the following procedures, when the platform is loaded.
- *Operated the machine at the "Lower control", when carrying out the adjustment.

Fig:2




1. If the platform is tilted downward.
 - 1) Retract boom fully, and set it horizontally.
 - 2) Open the two "Stop valves" located at "Lower control".
 - 3) Operate the "Extension switch" to "IN", and move the platform upward.
 - 4) When the platform gets its level, return the control switch to its neutral, and close the "Stop valves" firmly.
 - 5) Operate the machine thoroughly at the "Lower control", and make certain that the platform always stays level.
2. If the platform is tilted upward.
 - 1) Retract boom fully, and set it horizontally.
 - 2) Open the two "Stop valves" located at "Lower control".
 - 3) Operate the "Extension switch" to "OUT", and move the platform downward.
 - 4) When the platform gets its level, return the control switch to its neutral, and close the "Stop valves" firmly.
 - 5) Operate the machine thoroughly at the "Lower control", and make certain that the platform always stays level.

4. Air bleeding procedures



Caution:

- * When bleeding air, always operate the machine from the lower control panel.
 - * Always unload the platform completely, before carrying out these procedures.
1. Retract the boom fully and position it horizontally.
 2. Fully open the two stop valves installed on the combination valve.
 3. Switch the "Extension switch" to "IN" and tilt the platform fully upward.
 4. Now switch the "Extension switch" to "OUT" and tilt the platform fully downward.
 5. Perform the above steps 3 and 4 several times (3~4times).
 6. Return the platform to its level position, and firmly close the two stop valves.

Fig:3





LOWER LEVELLING CYLINDER



| | | | | | |
|---|---------------|----|---------------|----|----------------|
| 1 | Cylinder tube | 8 | O ring | 15 | Back-up ring |
| 2 | Bushing | 9 | U ring | 16 | O ring |
| 3 | Piston rod | 10 | Back-up ring | 17 | O ring |
| 4 | Bushing | 11 | Self-lock nut | 18 | Dust seal |
| 5 | Bushing | 12 | Cylinder head | 19 | Grease fitting |
| 6 | Lock plate | 13 | Bushing | — | — |
| 7 | Piston | 14 | U ring | — | — |



UPPER LEVELLING CYLINDER



| | | | | | |
|---|---------------|----|---------------|----|--------------------------|
| 1 | Cylinder tube | 8 | U ring | 15 | Dust seal |
| 2 | Bushing | 9 | Back-up ring | 16 | O ring |
| 3 | Collar | 10 | Self-lock nut | 17 | Lock plate |
| 4 | Piston rod | 11 | Cylinder head | 18 | O ring |
| 5 | Bushing | 12 | Bushing | 19 | Double pilot check valve |
| 6 | Piston | 13 | U ring | 20 | Bolt |
| 7 | O ring | 14 | Back-up ring | 21 | Spring washer |

DOUBLE PILOT CHECK VALVE (for Upper levelling cylinder)


This valve is mounted on the Upper levelling cylinder.
It confines the hydraulic oil into the Upper levelling cylinder to keep the platform level in an emergency situation such as hydraulic line failure.



| | | | | | |
|---|---------------|----|----------------|----|--------------|
| 1 | Valve housing | 6 | O ring | 11 | Spring |
| 2 | Plug | 7 | Back - up ring | 12 | Spring guide |
| 3 | Plug | 8 | Gasket | 13 | O ring |
| 4 | O ring | 9 | Valve seat | 14 | Plug |
| 5 | Piston | 10 | Check valve | 15 | Plug |




COMBINATION VALVE (for platform levelling system)

This valve consists of two Stop valves used for adjusting platform level, and two Relief valves which release excessively high pressure built up in the hydraulic circuit of the levelling system.




PLATFORM LEVEL SOLENOID VALVE

This valve is operated by the platform level switch to adjust the level of the platform.



DOUBLE PILOT CHECK VALVE (for platform levelling system)



This valve confines the hydraulic oil to the platform levelling system to maintain the level of platform.




| | |
|---|---------------|
| 1 | Valve housing |
| 2 | Valve seat |
| 3 | Check valve |
| 4 | Piston |
| 5 | Plug |
| 6 | O ring |
| 7 | Spring |
| 8 | Gasket |

4
ELECTRIC SECTION


UPPER CONTROL BOX



Fuse holder Detail




Inside view of control panel



Inside view of back panel

1. Electric circuit




LEVER POTENTIOMETER

The lever potentiometer consists of two parts. One which functions as a switch and one which controls variations of resistance. These two parts are operated simultaneously by the control lever.



The "OFF" section of the switch extends 4° to either side of the lever's central position. The switch will be turned "ON" when the lever is inclined in excess of 4° to either side.

The "OFF" section of the resistance control extends 5° to either side, and from there the resistance ($2k\Omega$) is varied as the control lever is inclined.



CONTROL BOARD



The board is installed in the "Upper control box".







CONTROL BOARD

With resistance R3 and R4

The board is installed in the "Upper control box".




LOWER CONTROL BOX




Identifications of Connectors

1. Electric circuit (for Spec : A6)



MAIN KEY SWITCH

The main key switch is located on the Lower control box.
 This supplies power to the "Upper" or "Lower" control.



Key position and ON/OFF conditions of each terminal

| | | Terminal NO. | | | | | |
|--------------|-------|--------------|-------|----|----|----|-----|
| | | 30 | 15/54 | 58 | 19 | 17 | 50a |
| Key position | OFF | ○ | | | | | |
| | Upper | ○ | — | ○ | | | |
| | Lower | ○ | ○ | | | | |
| | Glow | ○ | — | — | ○ | | |
| | Start | ○ | — | — | — | ○ | ○ |

VALVE CONTROL UNIT

The Valve control unit is installed within the electric circuit between the "Potentiometers" (or control switches) and the "Solenoids" of the main control valve.

When the Valve control unit inputs "Voltage variation" (sent from Potentiometer), it converts this "Voltage variation" into the "Ampere variation", and outputs it to the "Solenoids" of the main control valve.


Thus, the proportional operation of main control valve is achieved, when the potentiometer is operated at the upper control.

However, in case the "Control switch" is operated at the lower control, the main control valve is actuated as a conventional solenoid valve, since the control switch does not output "Voltage variation", which is necessary for proportional operation.


1. Specifications

| | |
|----------------|---------------------------------------|
| Rated voltage | DC-24V |
| Input voltage | DC0~10V |
| Output current | 0~800mA |
| Delay(Ramp) | 0~7seconds(when input voltage is 10V) |
| Dither | 50Hz |

2. Input/output characteristic



1. External view



2. Trimmers and their functions

| Operation \ Trimmer | | NULL | GAIN | DELAY | | DITHER | Tr |
|---------------------|-------|------|------|-------|-------|--------|------|
| | | | | UP | DOWN | | |
| Rotation | C.W | P1 | P2 | VR-1 | VR-2 | VR-31 | Tr-1 |
| | C.C.W | P3 | P4 | VR-4 | VR-5 | | Tr-2 |
| Extension | OUT | P5 | P6 | VR-7 | VR-8 | VR-32 | Tr-3 |
| | IN | P7 | P8 | VR-10 | VR-11 | | Tr-4 |
| Elevation | UP | P9 | P10 | VR-13 | VR-14 | VR-33 | Tr-5 |
| | DOWN | P11 | P12 | VR-16 | VR-17 | | Tr-6 |
| Travelling (Right) | FWD | P13 | P14 | VR-19 | VR-20 | VR-34 | |
| | REV | P15 | P16 | VR-22 | VR-23 | | |
| Travelling (Left) | FWD | P17 | P18 | VR-25 | VR-26 | VR-35 | |
| | REV | P19 | P20 | VR-28 | VR-29 | | |


| | | Travelling (Right) | Travelling (Left) |
|--|-----|--------------------|-------------------|
| Trimmer for adjusting "Input voltage" to Valve control unit, when conducting "Pivot turn". | | VR-36 | VR-37 |
| Trimmer for adjusting "Input voltage" to Valve control unit, when conducting "Spin turn". | MIN | VR-38 | VR-40 |
| | MAX | VR-39 | VR-41 |

3. LEDs and their functions


The LEDs and their functions installed on the Valve control unit are as shown in the table below.

| | LED.NO. | Color | ON/OFF conditions & functions | Remarks |
|-----------------------------------|---------|--------|---|--|
| LEDs for Output | LD 1 | Yellow | Output lines to Rotation solenoids } are { Normal → ON Faulty → OFF | LEDs are turned off, in case the solenoids or electric lines to solenoids get short circuit. |
| | LD 2 | Yellow | Output lines to Extension solenoids } are { Normal → ON Faulty → OFF | |
| | LD 3 | Yellow | Output lines to Elevation solenoids } are { Normal → ON Faulty → OFF | |
| | LD 4 | Yellow | Output lines to Travelling(Right) solenoids } are { Normal → ON Faulty → OFF | |
| | LD 5 | Yellow | Output lines to Travelling(Left) solenoids } are { Normal → ON Faulty → OFF | |
| LEDs for Limitatin | LD 6 | Yellow | OFF, when Emergency stop is operated. | |
| | LD 7 | Green | OFF, when Rotation C.W. limitation is applied. | |
| | LD 8 | Green | OFF, when Rotation C.C.W. limitation is applied. | |
| LEDs for "selector input signals" | LD 9 | Red | ON, when Rotation C.W. selector input signal exists. | |
| | LD10 | Red | ON, when Rotation C.C.W. selector input signal exists. | |
| | LD11 | Red | ON, when Extension OUT selector input signal exists. | |
| | LD12 | Red | ON, when Extension IN selector input signal exists. | |
| | LD13 | Red | ON, when Elevation UP selector input signal exists. | |
| | LD14 | Red | ON, when Elevation DOWN selector input signal exists. | |
| | LD15 | Red | ON, when Travelling(Right) FWD selector input signal exists. | |
| | LD16 | Red | ON, when Travelling(Right) REV selector input signal exists. | |
| | LD17 | Red | ON, when Travelling(Left) FWD selector input signal exists. | |
| | LD18 | Red | ON, when Travelling(Left) REV selector input signal exists. | |

4. Note on function (NO.1)




5. Note on function (NO.2)



INTERFACE BOARD


(without CE/us selector switch)

The interface board is located in the lower control box to control the electric system.




1. Electric circuit (for: without US/CE selector switch)

RCC-242C



1. Electric circuit (for : with CE/US selector switch)





ACCELERATOR MOTOR

The output shaft of "Accelerator motor" is connected to the "Fuel control lever" of "Injection pump", and control the engine rpm into 3 speeds.


Low speed(Idling) — 1.200rpm

Mid speed — 1.800rpm

High speed — 2.300rpm



1. Electric circuit



2. Inspection

Check the function of "Accelerator motor" as follows referring above chart.

| No. | Inspection Procedures |
|-----|--|
| 1 | Turn on "Switch D", and make sure the motor rotates clockwise, then stops at "High" position. |
| 2 | Turn on "Switch B", and make sure the motor rotates counter clockwise, then stops at "MID" position. |
| 3 | Turn on "Switch A", and make sure the motor rotates counter clockwise, then stops at "LOW" position. |
| 4 | Turn on "Switch C", and make sure the motor rotates clockwise, then stops at "MID" position. |

SLOPE SENSOR


The sensor (installed on the turntable) detects the tilt angle of the machine caused by a slope.

(for Spec: A3, A4)

3 degree sensor

The sensor stops its out-put power (DC24V), and activates the slope warning buzzer, in case the machine is inclined 3° or more.

| | |
|----------------|-----------------|
| Rated voltage | DC24V(DC10~32V) |
| Preset angle | 3°(2.5°~3.5°) |
| Output current | 200mA |



NOTE: The wire color of the slope sensor may be changed as follows.


Red → Brown, White → Black, Black → Blue

(for Spec: A6)

5 degree sensor

The sensor stops its out-put power (DC24V), and activates the slope warning buzzer, in case the machine is inclined 5° or more.



| | |
|----------------|-----------------|
| Rated voltage | DC24V(DC10~32V) |
| Preset angle | 5,5°(5° ~ 6°) |
| Output current | 100mA |



FOOT SWITCH

The foot switch is installed on the platform floor to stop the functions of Upper control levers and switches.


This will happen when the switch is not pressed down.




ELECTRIC COMPONENTS attached on ENGINE

1. Engine stop solenoid

| | |
|----------------|--------------------------------|
| Rated voltage | DC24V |
| Rated current | 10A or less |
| Actuating time | 10 seconds after switching off |




Function chart



The solenoid is switched on for about 10 seconds, when the power(+24V) applied on "Signal Line" is turned off, and switched off automatically after 10 seconds.



2. Glow indicator

| | |
|-----------------------|---------------|
| Rated voltage | DC24V |
| Rated current | 16.4A |
| Resistance | 0.054 Ω |
| Time reaches to 800°C | 20~25 seconds |




3. Starter motor

| | |
|---------------|-------|
| Rated voltage | DC24V |
| Rated output | 3.5Kw |







4. Safety relay

The relay is installed on the "Starter motor".




5. Alternator

| | |
|-----------------|-------|
| Rated voltage | DC24V |
| Out-put current | 20A |



6. Battery relay

| | |
|---------------|--|
| Rated voltage | DC24V |
| Rated current | 100A(continuously), 1.000A(30 seconds) |




5

ELECTRIC CIRCUIT for INDIVIDUAL SYSTEM


ENGINE CONTROL SYSTEM

(for Spec : A3, A4.) (for Serial NO: ~ 655367)




ENGINE CONTROL SYSTEM

(for Spec: A4, A6) (for Serial NO: 655368 ~)




ROTATION SYSTEM

(for Spec: A4, A6) (for Serial NO: 655368 ~)




EXTENSION SYSTEM

(for Spec: A3, A4) (for Serial NO: ~ 655367)




EXTENSION SYSTEM

(for Spec: AA, A6) (Serial NO: 655368 ~)



ELEVATION SYSTEM

(for Spec: A3, A4) (for Serial NO: ~ 655367)




Main control valve
NO. 1 (Elevation)

ELEVATION SYSTEM

(for Spec: A4, A-6)

(for Serial NO: 655368~)




This relay is switched on when the boom is operated, and stays off when the travelling is operated.

Main control valve NO. 1 (Elevation)


TRAVEL (RIGHT) SYSTEM

(for Spec: A3, A4) (for Serial NO: ~ 655367)




TRAVEL (RIGHT) SYSTEM

(for Spec: A4, A6) (for Serial NO: 655368~)




TRAVEL (LEFT) SYSTEM

(for Spec: A3, A4) (for Serial NO: ~ 655367)




TRAVEL (LEFT) SYSTEM

(for Spec: A4, A6) (for Serial NO: 655368~)



ACCELERATOR SYSTEM

(for Spec: A3)




ACCELERATOR SYSTEM


(for Spec: A4) (for Serial NO: 654747~655367)

Platform


- Accelerator system functions as follows, when the accelerator switch is set at AUTO position.
- ① Engine speed is automatically brought up to "High" (1,800 rpm), when "Boom" is operated.
 - ② Engine speed is automatically brought up to "High" (2,300 rpm), when "Travel" is operated.
 - ③ Engine speed stays at "Low" (1,200 rpm) even when "Travel" is operated, if one or both of the conditions listed below are satisfactory.
 - ⓐ Boom angle is over the horizontal.
 - ⓑ Boom is not fully retracted.



Boom



Turntable



ACCELERATOR SYSTEM






(for Spec: A4). (for Serial NO: 655368 ~)

Platform

- Accelerator system functions as follows, when the accelerator switch is set at AUTO position.
- ① Engine speed is automatically brought up to "HID" (1,800 rpm), when "Boom" is operated.
 - ② Engine speed is automatically brought up to "High" (2,300 rpm), when "Travel" is operated.
 - ③ Engine speed stays at "Low" (1,200 rpm) even when "Travel" is operated, if one or both of the conditions listed below are satisfactory.
 - ⊙ Boom angle is over the horizontal.
 - ⊙ Boom is not fully retracted.

Boom


Turntable



ACCELERATOR SYSTEM (for Spec: A6)

| Position of Accelerator s/w | Status of Boom | Operation performed | Tr 1 | Tr 2 | Engine speed |
|-----------------------------|---|---------------------|------|------|--------------|
| LOW | Any status | Boom | OFF | OFF | LOW |
| | Any status | Travel | ON | OFF | LOW |
| | Any status | Boom | ON | ON | MID |
| AUTO | Boom angle: Under the horizontal. (and) Boom length: Fully retracted. | Travel | ON | ON | HIGH |
| | Boom angle: Over the horizontal. (or) Boom length: Extended. | Travel | ON | OFF | LOW |
| | Any status | Travel | ON | ON | LOW |


The Tr1 and Tr2 on ICs are switched on or off according to the various conditions as shown in the table below to control the engine speed to LOW, MID and HIGH.



(for Spec : A3, A4)

PLATFORM SWING, PLATFORM LEVEL SYSTEM


(for Interface board without CE/US selector switch) (for Serial NO: ~ 655367)



(for Spec: A4, A6)

PLATFORM SWING, PLATFORM LEVEL SYSTEM


(for Interface board without CE/US selector switch) (for Serial NO: 655368~)



(for Spec: A3, A4)


PLATFORM SWING, PLATFORM LEVEL SYSTEM

(for Interface board CE/US selector switch) (for Serial NO: ~655367)




SLOPE WARNING, HORN and WORKING LIGHT SYSTEM

(for Spec : A3, A4.) (for Serial NO : ~ 655367)




SLOPE WARNING, HORN and WORKING LIGHT SYSTEM

(for Spec : A3, A4.) (for Serial NO: 655368~)




SLOPE WARNING, HORN and WORKING LIGHT SYSTEM

(for Spec : A6)




MOTION ALARM SYSTEM

(for Spec : A4, A6) (for Serial NO: 655368 ~)




EMERGENCY PUMP SYSTEM

(for Spec: A3, A4.) (for Serial NO: ~ 655367)



EMERGENCY PUMP SYSTEM

(for Spec: A4, A6) (for Serial NO: 655368~)



6

ADJUSTMENT SECTION


RELIEF VALVE P1 and P4

Adjust the "Preset pressure" of "Relief valves P1 and P4" installed on the "Main control valve No.1" as follows.

Preset pressure

Relief valve P1 ----- $210 \pm_0^5 \text{ kgf/cm}^2$ ($3,000 \pm_0^{70} \text{ PSI}$)

Relief valve P4 ----- $90 \pm_0^5 \text{ kgf/cm}^2$ ($1,280 \pm_0^{70} \text{ PSI}$)




1. Remove the plug on "Pressure test port" installed on the out - let line of "Pump NO.1", and set a "Pressure gauge" onto the pressure test port.
2. Start engine, retract boom fully, and hold the "Extension switch" at "IN" to actuate "Relief valve P1".
3. Read the pressure gauge while "Relief valve P1" is active, and adjust the pressure to $210 \pm_0^5 \text{ kgf/cm}^2$ ($3,000 \pm_0^{70} \text{ PSI}$) by turning "Adjust screw of "Relief valve P1".
4. Extend boom fully, and hold the "Extension switch" at "OUT" to actuate "Relief valve P4"
5. Read the pressure gauge while "Relief valve P4" is active, and adjust the pressure to $90 \pm_0^5 \text{ kgf/cm}^2$ ($1,280 \pm_0^{70} \text{ PSI}$) by turning "Adjust screw of "Relief valve P4".

RELIEF VALVE P2

To adjust the "Preset pressure" of Relief valve P2 installed on the Main control valve No.2, take the following steps.

Preset pressure..... $210^{\pm 5}$ kgf/cm² ($3,000^{\pm 70}$ PSI)




Main control valve NO.2

1. Remove the plug from the Pressure test port installed on the out - let line of Pump NO.2, and set a Pressure gauge onto the pressure test port.
2. Start engine, and insert something such as a Steel shaft between Drive sproket and the Track links on the right side travel motor to stop the rotation of travel motor.
3. Perform Travelling (Right) operation and actuate the Relief valve P2.
4. Read the pressure gauge while the Relief valve P2 is active, and adjust the pressure to $210^{\pm 5}$ kgf/cm² ($3,000^{\pm 70}$ PSI) by turning the adjustment screw of Relief valve P2.

RELIEF VALVE P3

To adjust the Preset pressure of Relief valve P3 installed on the Priority valve, take the following steps.

Preset pressure..... 140^{+5}_0 kgf/cm² ($2,000^{+70}_0$ PSI)



1. Remove the plug from the Pressure test port installed on the out - let line of Pump NO.2, and set a Pressure gauge onto the pressure test port.
2. Start engine, swing the Platform fully to the "Right", and hold the Platform swing switch at "Right" to actuate the Relief valve P3.
3. Read the Pressure gauge while Relief valve P3 is active, and adjust the pressure to 140^{+5}_0 kgf/cm² ($2,000^{+70}_0$ PSI) by turning the Adjustment screw of Relief valve P3.

OPERATIONAL SPEED

The following conditions must be strictly kept, when measuring or adjusting the operational speed.

| | |
|-------------------------------|---|
| * Hydraulic pump speed : | 2,300 rpm. (Without load) |
| * Maximum hydraulic pressure. | |
| for Main control system : | 210 kg/cm ² . (3,000 PSI) |
| for Sub control system : | 140 kg/cm ² . (2,000 PSI) |
| * Pump discharge volume : | More than 22 liters/min(5.8 gals/min). (At pump speed : 1,000 rpm) |
| * Hydraulic oil temperature : | 40°~ 60°C. |
| * Platform | No load condition. |

1. Measurement procedures of "Maximum operational speed"

Take the following items into consideration, when measuring each Maximum operational speed.

- *Measure each operational speed at least 3 times for the purpose of obtaining accurate data.
- *Operate the control levers fully up to the stroke ends, when measuring the operational speed by functioning the upper control.

1. Elevation. (Boom raising "Up"/ lowering "DOWN" speed)
Raise / lower the boom to its full stroke with the minimum boom length, and measure the boom raising "UP" and lowering "DOWN" speeds (seconds / stroke).
2. Extension (Boom extending "OUT"/ retracting "IN" speed)
Extend / retract the boom to its full stroke with the maximum boom angle, and measure the the boom extention "OUT" and retraction "IN" speeds (seconds / stroke).
3. Rotation. (Turn-table rotation speed)
Rotate the Turn-table with the "minimum boom length" and the "maximum boom angle", and measure the turn-table rotation speed (seconds / rev).
4. Travelling. (Travelling speed straight)
Travel the machine exactly 10 meters (10 yards) "Forward" and "REVERSE" on firm level ground, and measure the travelling speed (seconds / 10 meters, seconds / 10yards).

NOTE : Travel the machine with the minimum boom length and with a boom angle which is less than horizontal.

5. Travelling Pivot turn speed.

Perform "Pivot turn" to both Right and Left, and measure the "Pivot turn speed" (seconds/90°)

6. Travelling Spin turn speed.

Perform "Spin turn" operation C.W. and C.C.W, and measure the "Spin turn speed" (seconds/90°)

2. Specific "Maximum operational speed"

| Function | | Direction | Upper control | Lower control |
|------------|------------|-----------|--|-----------------------|
| Elevation | | UP | 70 ± 5 sec/stroke | 70 ± 5 sec/stroke |
| | | DOWN | 70 ± 5 sec/stroke | 70 ± 5 sec/stroke |
| Extension | | OUT | 35 ± 5 sec/stroke | 35 ± 5 sec/stroke |
| | | IN | 30 ± 5 sec/stroke | 30 ± 5 sec/stroke |
| Rotation | | C.W. | 150 ± 10 sec/rev. | 150 ± 10 sec/rev. |
| | | C.C.W. | 150 ± 10 sec/rev. | 150 ± 10 sec/rev. |
| Travelling | Straight | FWD | 32 ± 4 sec/10 meters (29 ± 3.5 sec/10 yards) | |
| | | REV | 32 ± 4 sec/10 meters (29 ± 3.5 sec/10 yards) | |
| | Pivot turn | Right | 17 ± 3 sec/ 90° | |
| | | Left | 17 ± 3 sec/ 90° | |
| | Spin turn | C.W. | 17 ± 3 sec/ 90° | |
| | | C.C.W. | 17 ± 3 sec/ 90° | |

3. Adjustment procedures of Operational speed

Each operational speed for "Elevation", "Extension", "Rotation" and "Travelling" is adjusted by each "Trimmer" on the Valve control unit as follows.

NOTE : The locations of each "Trimmer" on the Valve control unit is shown in the clause of : Trimmer identification on valve control unit.

Adjustment is to be carried out in the following order

1. Minimum Operational speed.
2. Maximum Operational speed.
3. Adjustment of "Tr" trimmers
4. Adjustment of "Delay" trimmers
5. Adjustment of "Pivot" turn speed
6. Adjustment of "Spin" turn speed

1. Minimum operational speed

NOTE : The "Minimum" operational speed is obtained, when each Control lever is actuated slightly at the Upper control.

1. Start the machine and lower the platform close to the ground.
2. Stop engine and open the Lower control box.

Then, set the Main key switch to the "UPPER" position.

3. Set a "Digital voltmeter" between each "PIN"⊕ on Valve control unit (listed below) and "Body earth" ⊖.

| Function | Direction | Pin NO. |
|--------------------|-----------|---------|
| Elevation | UP | V10 |
| | DOWN | V12 |
| Extension | OUT | V6 |
| | IN | V8 |
| Rotation | C.W. | V2 |
| | C.C.W. | V4 |
| Travelling (Left) | FWD | V18 |
| | REV | V20 |
| Travelling (Right) | FWD | V14 |
| | REV | V16 |

4. Move the Control lever slightly until the "LED" indicator (Red) (on Valve control unit) turns on, and take the reading from the voltmeter.

NOTE : *The reading on the Digital voltmeter is the "NULL" voltage.

*Higher "NULL" voltage causes increased Minimum operational speed.

*The reference value for each "NULL" voltage is as shown in the table below.

| Function | Direction | NULL trimmer | "NULL voltage" |
|--------------------|-----------|--------------|----------------|
| Elevation | UP | P9 | 0.32V |
| | DOWN | P11 | 0.32V |
| Extension | OUT | P5 | 0.32V |
| | IN | P7 | 0.32V |
| Rotation | C.W. | P1 | 0.32V |
| | C.C.W. | P3 | 0.32V |
| Travelling (Left) | FWD | P17 | 0.32V |
| | REV | P19 | 0.32V |
| Travelling (Right) | FWD | P13 | 0.32V |
| | REV | P15 | 0.32V |

Caution : When checking or adjusting "NULL" voltage for Travelling, operate both of the Travel control levers "Right" and "Left" slightly in the same direction.

5. Adjust each "NULL" trimmer (listed above), so that each hydraulic actuator is about to move, when each Control lever is actuated slightly.

NOTE : To increase the "NULL" voltage or "Minimum" operational speed, turn each "NULL" trimmer clockwise.

2. Maximum operational speed

NOTE : The "Maximum" operational speed is obtained, when each Control lever is actuated fully at the Upper control.

1. Start the machine and lower the platform close to the ground.
2. Stop the engine, and open the Lower control box.
Then, set the Main key switch to the "UPPER" position.
3. Set a "Digital voltmeter" between each "PIN"⊕ on Valve control unit (listed below) and "Body earth"⊖.

| Function | Direction | "Pin" NO. |
|--------------------|-----------|-----------|
| Elevation | UP | V10 |
| | DOWN | V12 |
| Extension | OUT | V6 |
| | IN | V8 |
| Rotation | C.W. | V2 |
| | C.C.W. | V4 |
| Travelling (Left) | FWD | V18 |
| | REV | V20 |
| Travelling (Right) | FWD | V14 |
| | REV | V16 |

4. Operate the Control lever fully and take the reading from the voltmeter.

NOTE : * The reading on the Digital voltmeter is the "GAIN" voltage.

* Higher "GAIN voltage" causes increased Maximum operational speed.

* The reference value for each "GAIN" voltage is as shown in the table below.

| Function | Direction | "GAIN trimmer" | "GAIN voltage" |
|--------------------|-----------|----------------|----------------|
| Elevation | UP | P10 | 0.50V |
| | DOWN | P12 | 0.52V |
| Extension | OUT | P6 | 0.59V |
| | IN | P8 | 0.57V |
| Rotation | C.W. | P2 | 0.43V |
| | C.C.W. | P4 | 0.45V |
| Travelling (Left) | FWD | P18 | 0.60V |
| | REV | P20 | 0.60V |
| Travelling (Right) | FWD | P14 | 0.60V |
| | REV | P16 | 0.60V |

Caution : When checking or adjusting "GAIN" voltage for Travelling, operate both of the Travel control levers fully in the same direction.

5. Adjust each "GAIN" trimmer (listed in the table above), so that the each "Maximum" operational speed becomes a Specific value.

NOTE : * To increase the "GAIN" voltage or "Maximum" operational speed, turn each "GAIN" trimmer clockwise.

3. Adjustment of "Tr trimmers"

The "Tr" trimmers are adjusted to vary the "Maximum" operational speed which is obtained by actuating the "Control switches" at Lower control.

Follow the descriptions below to adjust the speed.

1. Stop engine, and open the Lower control box.
Then, set the Main key switch to the "LOWER" position.
2. Set a "Digital voltmeter" between each "Pin⊕" on valve control unit (listed below) and Body earth ⊖.

| Function | Direction | "Pin" NO. |
|-----------|-----------|-----------|
| Elevation | UP | V10 |
| | DOWN | V12 |
| Extension | OUT | V6 |
| | IN | V8 |
| Rotation | C.W. | V2 |
| | C.C.W. | V4 |

3. Operate the each Control switch at Lower control box, and take the reading from the voltmeter.

NOTE : The reading on the Digital voltmeter is the "Out put" voltage of valve control unit.

4. Turn the each "Tr" trimmer (listed in the table below) to adjust the speed.

NOTE : *An increase to the output voltage causes an increase to the speed.
*To increase the Out put voltage, turn each "Tr" trimmer clockwise.

| Function | Direction | Tr trimmer NO. | Output voltage |
|-----------|-----------|----------------|----------------|
| Elevation | UP | Tr 5 | 0.50V |
| | DOWN | Tr 6 | 0.52V |
| Extension | OUT | Tr 3 | 0.59V |
| | IN | Tr 4 | 0.57V |
| Rotation | C.W. | Tr 1 | 0.43V |
| | C.C.W. | Tr 2 | 0.45V |

4. Adjustment of "DELAY trimmers".

The "DELAY" trimmers can be adjusted to start or stop each operation more gradually, or quickly.

| Function | | Delay trimmer | |
|--------------------|--------|---------------|-------|
| Elevation | UP | UP | VR 13 |
| | | DOWN | VR 14 |
| | DOWN | UP | VR 16 |
| | | DOWN | VR 17 |
| Extension | OUT | UP | VR 7 |
| | | DOWN | VR 8 |
| | IN | UP | VR 10 |
| | | DOWN | VR 11 |
| Rotation | C.W. | UP | VR 1 |
| | | DOWN | VR 2 |
| | C.C.W. | UP | VR 4 |
| | | DOWN | VR 5 |
| Travelling (Left) | FWD | UP | VR 25 |
| | | DOWN | VR 26 |
| | REV | UP | VR 28 |
| | | DOWN | VR 29 |
| Travelling (Right) | FWD | UP | VR 19 |
| | | DOWN | VR 20 |
| | REV | UP | VR 22 |
| | | DOWN | VR 23 |

NOTE :

* To start each function more gradually, turn the each Delay trimmer "UP" clockwise.

* To stop each function more gradually, turn the each Delay trimmer "DOWN" clockwise.

Adjustment of DITHER trimmers.

The "DITHER" trimmers are adjusted to give the correct "Vibration" to the "Output power" of Valve control unit.

NOTE : Do not adjust the "Dither" trimmers, as they have been precisely adjusted by the manufacturer.

| Function | Dither trimmer |
|--------------------|----------------|
| Elevation | VR - 33 |
| Extension | VR - 32 |
| Rotation | VR - 31 |
| Travelling (Left) | VR - 35 |
| Travelling (Right) | VR - 34 |


5. Adjustment of "Pivot turn" speed

The "Pivot turn" speed is adjusted by the trimmers installed on the Valve control unit as follows.


Caution: The Pivot turn speed should be adjusted after having adjusted "Straight travelling speed".

The main key switch is to be set at its "UPPER" position, when adjusting the pivot turn speed.

1. Pivot Turn (Right)

| NO. | Adjustment procedures | Remarks |
|-----|--|--|
| 1. | Set a Digital volt-meter between the "Check pin (TP - D)" ⊕ on Valve control unit and "GND" ⊖. |  <p>Pivot turn (Right)</p> |
| 2. | Operate the "Travel lever (Left)" fully to "FWD", and read the voltmeter. Voltage (reference) 7.0V | |
| 3. | Adjust the voltage by Trimmer (VR37). (The higher voltage causes the faster pivot turn speed.) Specific pivot turn speed $17 \pm 3 \text{ sec}/90^\circ$ | |

2. Pivot Turn (Left)



| NO. | Adjustment procedures | Remarks |
|-----|--|--|
| 1. | Set a Digital volt-meter between the "Check pin (TP - C)" ⊕ on Valve control unit and "GND" ⊖. |  <p>Pivot turn (Left)</p> |
| 2. | Operate the "Travel lever (Right)" fully to "FWD", and read the voltmeter. Voltage (reference) 7.0V | |
| 3. | Adjust the voltage by Trimmer (VR36). (The higher voltage causes the faster pivot turn speed.) Specific pivot turn speed $17 \pm 3 \text{ sec}/90^\circ$ | |

6. Adjustment of "Spin turn" speed.

The "Spin turn" speed is adjusted by the trimmers installed on the Valve control unit as follows.


Caution: The Spin turn speed should be adjusted after having adjusted "Straight travelling speed".

The main key switch is to be set at its "UPPER" position, when adjusting the spin turn speed.

| NO. | Adjustment procedures | Remarks |
|-----|---|---|
| 1. | Set a Digital volt meter between the "Check pin (TP - C)" ⊕ on Valve control unit and "GND" ⊖. | |
| 2. | Operate "Travel (Left) lever" to "REV" slightly, and "Travel (Right) lever" to "FWD" fully. |  <p>Spin turn (C.W.)</p> |
| 3. | Hold the Travel levers at the above positions, and adjust the voltage (V ₁) to 7.0V by Trimmer (VR - 38). | |
| 4. | Operate "Travel (Left) lever" to "REV" fully, and "Travel (Right) lever" to "FWD" fully. | |
| 5. | Hold the Travel levers at the above positions, and adjust the voltage (V ₂) to 5.5V by Trimmer (VR - 39). | |
| 6. | Set a Digital voltmeter between the "Check pin (TP - D)" ⊕ on Valve control unit and "GND" ⊖. | |
| 7. | Operate "Travel (Right) lever" to "REV" slightly, and "Travel (Left) lever" to "FWD" fully. |  <p>Spin turn (C.C.W.)</p> |
| 8. | Hold the Travel levers at the above positions, and adjust the voltage (V ₃) to 7.0V by Trimmer (VR - 40). | |
| 9. | Operate "Travel (Right) lever" to "REV" fully, and "Travel (Left) lever" to "FWD" fully. | |
| 10. | Hold the Travel levers at the above positions, and adjust the voltage (V ₄) to 5.5V by Trimmer (VR - 41). | |
| 11. | Adjust the Spin turn speed CW & CCW, by varying the voltage (V ₂ & V ₄). The higher voltage causes the faster Spin turn speed. | |

Specific spin turn speed:
 C.W. ... 17 ± 3 sec / 90°
 C.C.W. ... 17 ± 3 sec / 90°

4. Trimmer's Identification on "Valve control unit"



ADJUSTMENT DATA SHEET

Date : _____ Serial NO : _____

| Function | Elevation | | Extension | | Rotation | | Travel (Left) | | Travel (Right) | |
|----------------|-------------------|---------|------------|------------|------------|------------|--------------------|---------------------|---------------------|---------------------|
| | UP | DOWN | OUT | IN | CW | CCW | FOR | REV | FOR | REV |
| Direction | V 10 | V 12 | V 6 | V 8 | V 2 | V 4 | V 18 | V 20 | V 14 | V 16 |
| Pin No. | P 9 | P 11 | P 5 | P 7 | P 1 | P 3 | P 17 | P 19 | P 13 | P 15 |
| NULL trimmer | (0.33V) | (0.33V) | (0.33V) | (0.33V) | (0.33V) | (0.33V) | (0.33V) | (0.33V) | (0.33V) | (0.33V) |
| NULL voltage | Before adjustment | | | | | | | | | |
| | After adjustment | | | | | | | | | |
| GAIN trimmer | P 10 | P 12 | P 6 | P 8 | P 2 | P 4 | P 18 | P 20 | P 14 | P 16 |
| GAIN voltage | Before adjustment | | (0.59V) | | (0.45V) | | (0.60V) | | (0.60V) | |
| | After adjustment | | | | | | | | | |
| DELAY trimmer | UP | | VR 7 | VR 10 | VR 1 | VR 4 | VR 25 | VR 28 | VR 19 | VR 22 |
| | DOWN | | VR 8 | VR 11 | VR 2 | VR 5 | VR 26 | VR 29 | VR 20 | VR 23 |
| Tr trimmer | Tr 5 | Tr 6 | Tr 3 | Tr 4 | Tr 1 | Tr 2 | / | | / | |
| DITHER trimmer | VR 33 | | VR 32 | | VR 31 | | VR 35 | | VR 34 | |
| Spec., speed | UPPER control | | 70 ± 5 sec | 70 ± 5 sec | 30 ± 5 sec | 30 ± 5 sec | 150 ± 10 sec/1turn | 32 ± 4 sec/10.7 | 32 ± 4 sec/10m | 29 ± 3.5 sec/10 yds |
| | LOWER control | | 70 ± 5 sec | 70 ± 5 sec | 30 ± 5 sec | 30 ± 5 sec | 150 ± 10 sec/1turn | 29 ± 3.5 sec/10 yds | 29 ± 3.5 sec/10 yds | |

7
A P P E N D I X







TROUBLE SHOOTING

| NO. | Problem | Cause | Remedy |
|-----|--|---|---|
| 1. | "Starter motor" does not run on either Upper or Lower control. | 1)"Emergency stop s/w" on Lower or Upper control box is pressed. (Both Power lamps on "Lower" and "Upper" controls turn off.) 2)"Emergency stop fuse F4 (10A) " in Lower control box has blown. (Power lamps turn off.) 3)"Main fuse F5 (20A) " in Lower control box has blown. (Power lamps turn off.) 4)"Engine start fuse F6 (10A) " in Lower control box has blown. (Power lamps turn on.) 5)"Fusible link" (30A) has blown. | Pull the Emergency stop s/w to turn on Power lamps. Replace the fuse. Replace the fuse. Replace the fuse. Release the fusible link. |
| 2. | "Starter motor" does not run at Upper control. | 1)"Foot S/W" is pressed. 2)"Engine start fuse F2 (3A) " in Upper control box has blown. | Release the foot switch and press the "Engine start switch". Replace the fuse. |
| 3. | "Starter motor" runs, but engine does not start. | 1) Fuel tank is empty. 2) Engine is cool. | Fill fuel, bleed air, and start engine. Preheat "Glow plugs", and start engine. |
| 4. | Engine does not stop. | 1)"Engine stop fuse F1 (30A) " in Lower control box has blown. | Replace the fuse. |
| 5. | Engine stopped naturally, and does not start again. | 2) Fuel tank is empty. | Fill fuel, bleed air, and start engine. |

TROUBLE SHOOTING

| NO. | Problem | Cause | Remedy |
|-----|---|---|--|
| 6. | The upper control is non-operational, except for the "Horn" and "Working light". | 1)"Foot switch" is not pressed. 2)"Main key switch" is set at "Lower" position. | Press Foot switch, and operate. Set the key switch to the "Upper" position. |
| 7. | "Elevation", "Extension", "Rotation" and "Travel" operations are not functioning either "Lower" or "Upper" control. | "Fuse" on Valve control unit installed in Lower control box has blown. | Replace the fuse. |
| 8. | Platform swing, level, and Emergency pump operation on Upper control are not functioning. | "Platform swing, level, & Emergency pump fuse F3 (10A)" in Upper control box has blown. | Replace the fuse. |
| 9. | "Accelerator motor" does not work from either the "Upper" or "Lower" control. | "Accelerator motor Fuse F2 (5A)" in Lower control box has blown. | Replace the fuse. |
| 10. | "Accelerator s/w" on Upper control does not work. | "Accelerator fuse F4 (3A)" in Upper control box has blown. | Replace the fuse. |
| 11. | "Horn" does not work. | "Horn fuse F1 (10A)" has blown in Upper control box. | Replace the fuse. |
| 11. | "Working light" does not work. | "Working light fuse F5 (5A)" in Upper control box has blown. | Replace the fuse. |
| 12. | "Buzzer" sounds at Upper control. | Machine is inclined 3° or more due to slope. | Lower the platform, and set the machine on level ground. |
| 13. | Platform loses level quite often. | "Platform level adjustment valves" are not closed firmly. | Close the valves firmly. |


Identifications of "Control devices" and "Fuses"






| | |
|----|--|
| 1 | Hour meter |
| 2 | Metal connector(for Optional Remote control) |
| 3 | _____ |
| 4 | Elevation switch |
| 5 | Emergency pump switch |
| 6 | Extension switch |
| 7 | Accelerator switch |
| 8 | Rotation switch |
| 9 | Emergency stop switch |
| 10 | Charge warning lamp |
| 11 | Engine water temp lamp |
| 12 | Engine oil pressure lamp |
| 13 | Glow indicator lamp |
| 14 | Main key switch |
| 15 | Power lamp |










| | |
|----|-------------------------|
| 1 | Working light switch |
| 2 | Accelerator switch |
| 3 | Rotation control lever |
| 4 | Extension control lever |
| 5 | Elevation control lever |
| 6 | Travel control lever |
| 7 | Power lamp |
| 8 | Engine start switch |
| 9 | Emergency stop switch |
| 10 | Platform swing switch |
| 11 | Emergency pump switch |
| 12 | Horn switch |
| 13 | Platform level switch |

HYDRAULIC CIRCUIT DIAGRAM




IDENTIFICATIONS OF HYDRAULIC COMPONENTS





KEY SWITCH

| | | | | | | |
|-----|-----|-------|-----|-----|----|----|
| | 45A | 13A | 33A | 33A | 9A | 9A |
| UP | 30 | 15/54 | 19 | 17 | 50 | 58 |
| OFF | | | | | | |
| LOW | | | | | | |
| CLW | | | | | | |
| STR | | | | | | |




KEY SWITCH

| | 45A | 13A | 33A | 33A | 9A | 9A |
|-----|-----|-----|-----|-----|----|----|
| UP | G | | | | | |
| OFF | G | | | | | |
| LOW | G | | | | | |
| CLW | G | | | | | |
| STR | G | | | | | |

ELECTRIC CIRCUIT DIAGRAM

(for Spec: A6)


602-14132






KEY SWITCH

| | 45A | 13A | 33A | 33A | 9A | 9A |
|-----|-----|-----|-------|-----|-------|------|
| UP | 0 | 30 | 15/54 | 19 | 17.50 | a 58 |
| OFF | 0 | | | | | 0 |
| LOW | 0 | 0 | | | | |
| GLW | 0 | | 0 | | | |
| STR | 0 | | | 0 | | |


IDENTIFICATIONS OF ELECTRIC COMPONENTS



ELECTRIC WIRE HARNESS



ELECTRIC WIRING CHART



TIGHTENING TORQUE STANDARD

1) Hexagon Bolts and Nuts (8.8T)

Material : S45C

Tensile strength : 80 kgf/mm²

Yield point : 64 kgf/mm²

Brinell hardness : 225 ~ 300

| Size mm | Pitch mm | Tightening torque | |
|------------|-------------|-------------------|-------------|
| | | kgf - m | ft - lb |
| 6 | 1.0 | 0.68 ~ 0.92 | 5 ~ 7 |
| 8 | 1.25 | 1.63 ~ 2.21 | 12 ~ 16 |
| 10 | 1.5 | 3.22 ~ 4.36 | 23 ~ 32 |
| 12 | 1.75 | 5.60 ~ 7.57 | 41 ~ 55 |
| 14 | 2.0 | 8.92 ~ 12.1 | 65 ~ 88 |
| 16 | 2.0 | 13.7 ~ 18.5 | 99 ~ 134 |
| 18 | 2.5 | 18.1 ~ 24.5 | 131 ~ 177 |
| 20 | 2.5 | 25.3 ~ 34.2 | 183 ~ 247 |
| 22 | 2.5 | 34.2 ~ 46.2 | 247 ~ 334 |
| 24 | 3.0 | 43.7 ~ 59.2 | 316 ~ 428 |
| 27 | 3.0 | 63.4 ~ 85.8 | 459 ~ 621 |
| 30 | 3.5 | 86.3 ~ 116.8 | 624 ~ 845 |
| 33 | 3.5 | 116.5 ~ 157.6 | 843 ~ 1140 |
| 36 | 4.0 | 150.2 ~ 203.3 | 1086 ~ 1471 |
| 39 | 4.0 | 193.1 ~ 261.2 | 1397 ~ 1889 |
| 42 | 4.5 | 214.5 ~ 290.2 | 1552 ~ 2099 |
| 45 | 4.5 | 266.2 ~ 360.2 | 1926 ~ 2605 |
| 48 | 5.0 | 321.4 ~ 434.8 | 2325 ~ 3145 |
| 52 | 5.0 | 412.7 ~ 558.4 | 2985 ~ 4039 |

2) Hexagon Socket Head Cap Screws (10.9T)

Material : SCM435

Tensile strength : 100 kgf/mm²

Yield point : 90 kgf/mm²

Brinell hardness : 280 ~ 365

Color : Black

| Size mm | Pitch mm | Tightening torque | |
|------------|-------------|-------------------|-------------|
| | | kgf - m | ft - lb |
| 6 | 1.0 | 1.22 ~ 1.65 | 9 ~ 12 |
| 8 | 1.25 | 2.94 ~ 3.98 | 21 ~ 29 |
| 10 | 1.5 | 5.80 ~ 7.84 | 42 ~ 57 |
| 12 | 1.75 | 10.1 ~ 13.6 | 73 ~ 98 |
| 14 | 2.0 | 16.1 ~ 21.7 | 116 ~ 157 |
| 16 | 2.0 | 24.6 ~ 33.2 | 178 ~ 240 |
| 18 | 2.5 | 32.6 ~ 44.1 | 236 ~ 319 |
| 20 | 2.5 | 45.6 ~ 61.6 | 330 ~ 445 |
| 22 | 2.5 | 61.5 ~ 83.2 | 445 ~ 602 |
| 24 | 3.0 | 78.7 ~ 106.5 | 569 ~ 770 |
| 27 | 3.0 | 114.1 ~ 154.4 | 825 ~ 1116 |
| 30 | 3.5 | 155.4 ~ 210.2 | 1124 ~ 1570 |
| 33 | 3.5 | 209.6 ~ 283.6 | 1515 ~ 2050 |
| 36 | 4.0 | 270.4 ~ 365.9 | 1955 ~ 2645 |
| 39 | 4.0 | 347.5 ~ 470.2 | 2512 ~ 3340 |
| 42 | 4.5 | 386.1 ~ 522.4 | 2792 ~ 3777 |
| 45 | 4.5 | 479.2 ~ 648.3 | 3465 ~ 4687 |
| 48 | 5.0 | 578.5 ~ 782.7 | 4183 ~ 5659 |
| 52 | 5.0 | 742.6 ~ 1011 | 5369 ~ 7310 |

SME-906

INSPECTION MANUAL
SELF PROPELLED AERIAL PLATFORM
SP,SR SERIES



1152, RYOKE, AGE0, SAITAMA, JAPAN.

I N D E X

| | |
|--|------|
| Procedures of Daily inspection..... | 8-1 |
| Daily inspection check sheet..... | 8-3 |
| Procedures of Periodical inspection..... | 8-5 |
| Procedures of Function test..... | 8-11 |
| Periodical inspection check sheet..... | 8-12 |

DAILY INSPECTION PROCEDURES

The inspection is to be carried out on firm level ground.

POWER UNIT

| UNIT | ITEM | DESCRIPTION |
|--------------------------|----------------------|--|
| Radiator. | Cooling water level. | Remove radiator cap and check the cooling water level. |
| Battery. | Electrolyte level. | Remove filler cap and check the electrolyte level. |
| Oil pan. | Engine oil level. | Check oil level. |
| Fuel tank. | Fuel level. | Check fuel level. |
| Hydraulic oil reservoir. | Hydraulic oil level. | Lower platform to its lowest position, retract jacks fully, and check oil level. |

CARRIER

| | | |
|--------------------|--|---|
| Tyre. | Excessive wear, cuts | Check tyres for excessive wear and cuts. |
| Wheel nuts. | Looseness. | Check wheel nuts for looseness. |
| Steering linkages. | Deformation, cracks. | Check steering linkages for deformation and cracks. |
| Travel motor unit. | Oil leakage. | Check the unit for oil leakage. |
| Carrier frame. | Deformation, cracks. | Check carrier frame for deformation and cracks. |
| Crawler. | Track link, shoes. (Excessive wear, tension.) | Check track link and shoes for excessive wear and abnormal tension. |

OUTRIGGERS

| | | |
|--------------------------|----------------------|--|
| Outrigger arm jack post. | Cracks, deformation. | Extend all of the outriggers and jacks fully, and check for cracks, deformation. |
| Jack cylinder. | Oil leakage. | Check each jack cylinder for oil leakage. |
| | Natural descent. | 1. Extend all jacks and ground them. 2. Check each jack cylinder if it is retracted due to the weight of machine. |

CONTROL SYSTEM

| | | |
|---------------------------|----------------------|---|
| Control levers, switches. | Function. | Operate all of the control levers, switches and check that their functions are operating correctly. |
| | Excessive free play. | Operate all of the control levers, switches and check for excessive free play. |

PLATFORM

| UNIT | ITEM | DESCRIPTION |
|---------------------------|----------------------------|---|
| Platform leveling system. | Function. | Operate the boom by the lower control, and check that the platform always keeps its level position. |
| Platform Swing device | Deformation, cracks, wear. | Check platform swing device for deformation, cracks, and wear. |

SAFETY DEVICE

| | | |
|--|-----------|---|
| Engine start stop system. | Function. | Test the engine start/stop switches at upper control and check they function correctly. |
| Emergency pump. | Function. | Stop engine, operate boom by emergency pump and check it functions correctly. |
| Foot switch. | Function. | Operate the machine using the upper control, release foot switch, and check if all of the function stops immediately. |
| Slope warning buzzer. | Function. | Turn on main key switch and make sure the slope warning buzzer sounds for a second just after turning on. |
| Alarm horn. | Function. | Press horn switch at upper control, and check it functions correctly. |
| Motion alarm buzzer | Function. | Operate the control levers, and switches then check that the motion alarm buzzer sounds. |
| Safety switch | Function. | Operate the safety switch, and check that the engine stops and that the power lamps turn off. |
| Working range controller. Moment limiter. | Function. | Operate the boom using the lower control, and check that it functions correctly. |

DAILY INSPECTION CHECK SHEET

POWER UNIT

| UNIT | ITEM | RESULTS | | | | | | | | | | | |
|--------------------------|----------------------|---------|--|--|--|--|--|--|--|--|--|--|--|
| (DATE) → | | | | | | | | | | | | | |
| Radiator. | Cooling water level. | | | | | | | | | | | | |
| Battery. | Electrolyte level. | | | | | | | | | | | | |
| Oil pan. | Engine oil level. | | | | | | | | | | | | |
| Fuel tank. | Fuel level. | | | | | | | | | | | | |
| Hydraulic oil reservoir. | Hydraulic oil level. | | | | | | | | | | | | |

CARRIER

| | | | | | | | | | | | | | |
|--------------------|--|--|--|--|--|--|--|--|--|--|--|--|--|
| Tyre. | Excessive wear, cuts | | | | | | | | | | | | |
| Wheel nuts. | Looseness. | | | | | | | | | | | | |
| Steering linkages. | Deformation, cracks. | | | | | | | | | | | | |
| Travel motor unit. | Oil leakage. | | | | | | | | | | | | |
| Carrier frame. | Deformation, cracks. | | | | | | | | | | | | |
| Crawler. | Track link, shoes. (Wear, tension.) | | | | | | | | | | | | |

TURNTABLE

| | | | | | | | | | | | | | |
|--------------------|-----------|--|--|--|--|--|--|--|--|--|--|--|--|
| Rotation gear box. | Function. | | | | | | | | | | | | |
|--------------------|-----------|--|--|--|--|--|--|--|--|--|--|--|--|

CONTROL SYSTEM

| | | | | | | | | | | | | | |
|---------------------------|------------|--|--|--|--|--|--|--|--|--|--|--|--|
| Control levers, switches. | Function. | | | | | | | | | | | | |
| | Free play. | | | | | | | | | | | | |

BOOM

| | | | | | | | | | | | | | |
|--------------------------------|----------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| Boom. | Deformation, cracks. | | | | | | | | | | | | |
| Boom pivot pin. | Any damage. | | | | | | | | | | | | |
| Extension, Elevation cylinder. | Oil leakage. | | | | | | | | | | | | |
| | Natural descent. | | | | | | | | | | | | |

PLATFORM

| | | | | | | | | | | | | | |
|---------------------------|----------------------------|--|--|--|--|--|--|--|--|--|--|--|--|
| Platform leveling system. | Function. | | | | | | | | | | | | |
| Platform & swing device. | Deformation, cracks, wear. | | | | | | | | | | | | |

SAFETY DEVICE

| UNIT | ITEM | RESULTS | | | | | | | | | | | |
|---|-----------|---------|--|--|--|--|--|--|--|--|--|--|--|
| (DATE) → | | | | | | | | | | | | | |
| Engine start, stop system. | Function. | | | | | | | | | | | | |
| Emergency pump. | Function. | | | | | | | | | | | | |
| Foot switch. | Function. | | | | | | | | | | | | |
| Slope warning buzzer. | Function. | | | | | | | | | | | | |
| Alarm horn. | Function. | | | | | | | | | | | | |
| Motion alarm buzzer. | Function. | | | | | | | | | | | | |
| Safety switch. | Function. | | | | | | | | | | | | |
| Working range controller, Moment limiter. | Function. | | | | | | | | | | | | |
| | | | | | | | | | | | | | |

PERIODICAL INSPECTION PROCEDURES

Carry out both of the descriptions for Monthly and Annual inspections when conducting Annual inspection.

| UNIT | ITEM | DESCRIPTION | |
|-------------------------|--|--|--|
| | | MONTHLY INSPECTION | ANNUAL INSPECTION |
| Engine | Water, oil leakage. | Check for water and oil leakage thoroughly. | ← |
| | Radiator. | Check for water level, contamination and replenish or change the water if necessary. | ← |
| | | Check the function of radiator cap and for any damage to the radiator thoroughly. | |
| | Air filter. | Check air filter and clean or replace the element, if necessary. | ← |
| | Water separator. | Drain water from water separator. | Disassemble and clean thoroughly. (Cleaning interval ; Every 6 months.) |
| | Fuel filter. | Check filter for fuel leakage. | Replace the element. (Replacement interval ; Every 600 hours.) |
| | Battery. | Check for the electrolyte level and clean battery terminals. | ← |
| | Fan belt. | Check for wear and tension. | ← |
| | Alternator, starter. | Check the function. | ← |
| | Valve clearance. | | Remove tappet cover and adjust valve clearance. (Adjustment interval ; Every 1,200 hours.) |
| | Engine oil. | Check oil level and contamination. | Change engine oil. (Replacement interval ; Every 200 hours.) |
| | Oil filter. | Check filter for oil leakage. | Replace the element. (Replacement interval ; Every 400 hours.) |
| | Fuel tank. | Check filter for oil leakage. | Drain fuel and clean the tank. |
| Hydraulic oil reservoir | Oil leakage. | Check for oil leakage. | ← |
| | Anchor bolts. | Check the bolts for looseness. | ← |
| | Stop valve. | Check stop valves for oil leakage and any other damage. | ← |
| | Oil level, contamination, viscosity, water content, oxidation. | Check oil level. | Stir oil in the reservoir, take out sample(60cc) and check the following items. |

| UNIT | ITEM | MONTHLY INSPECTION | ANNUAL INSPECTION |
|-------------------------|---------------------------------|---|--|
| Hydraulic oil reservoir | | | -Contamination ; Within NAS class 12. -Viscosity ; Within 10% ± Standard. -Water content ; Less than 0.5%. -Oxidation ; Less than 0.4mgKOR/g. (Oil change interval ; 1,200 hours or Annually) |
| Hydraulic filter. | Oil leakage, any other damage. | Check filters for oil leakage. | ← |
| | Replacement of filter element. | | Replace the element. (Replacement interval ; 1200 hours or Annually) |
| Hydraulic pump. | Abnormal noise, excessive heat. | Run the pump and check for the items. | ← |
| | Oil leakage. | Run the pump with maximum pressure and check for oil leakage. | ← |
| | Pump bracket, anchor bolts. | Check pump bracket for cracks, deformation, and anchor bolts for looseness. | |
| Wheels (SP series) | Tyre. | Check for excessive wear and cuts. | ← |
| | Wheel nuts. | Check for looseness. Tightening torque ; 25-30kg-m.(180~220ft-lb) | ← |
| Crawler. (SR series) | Track shoe, link. | Check for tension, and wear. | ← |
| | Drive sprocket, Idle wheel. | Check for excessive wear and cracks. | ← |
| | Track roller, carrier roller. | Check for wear and oil leakage. | ← |
| Travel motor unit | Oil leakage, external damages. | Check for the items. | ← |
| | Gear oil. | Check oil level. | Change gear oil. (Oil change interval ; 1,200 hours or Annually) |
| | Abnormal noise, excessive heat. | Run the motor and check the motor, gear box for the items. | ← |
| | Bolts, nuts. | Check for looseness. | ← |

| UNIT | ITEM | MONTHLY INSPECTION | ANNUAL INSPECTION |
|------------------------------------|-------------------------------------|--|--|
| Steering mechanism. (SP serise) | Linkages. | Check for deformation, cracks. | ← |
| | Wheel bearings. | | Jack up the machine and check the wheel bearings for excessive free play and any other damage. |
| | Steering cylinder. | Operate the cylinder and check for oil leakage, abnormal function. | ← |
| | Lubrication. | Supply grease to each grease fitting. | ← |
| Travel speed limit system. | Travel speed. | Perform travelling operation with extended boom or setting boom over the horizontal and make sure the travelling speed is LOW. | ← |
| | Flow divider valve. | Check the valves for oil leakage. | ← |
| | Travel speed select solenoid valve. | Check the solenoid valve for oil leakage. | ← |
| | Limit switch. | Check the limit switches for any damage. | ← |
| Carrier, frame | Deformation, cracks. | Check the frame for the items. | ← |
| Turntable. | Deformation, cracks. | Check turntable for the items. | ← |
| | Anchor bolts. | | Check anchor bolts for looseness. |
| T.T.B. (Turn Table Bearing) | Ring gear. | Check ring gear for excessive wear, cracks. | ← |
| | Bearings. | Rotate T.T.B. and check for abnormal noise and any other fault. | Check the T.T.B. for free play. serviceable limit ; 3 mm(0.12 in) |
| | Anchor bolts. | Check bolts for looseness. | ← |
| | Lubrication. | Supply grease to each grease fitting. | ← |
| Rotation motor, gear box. | Oil leakage. | Check gear box and motor for oil leakage. | ← |
| | Abnormal noise, excessive heat. | Run the motor and check for the items. | ← |
| | Bolts, nuts. | Check bolts, and nuts for looseness. | ← |

| UNIT | ITEM | MONTHLY INSPECTION | ANNUAL INSPECTION |
|---------------------------|---|---|---|
| Rotation motor, gear box. | Pinion gear. | Check pinion gear for wear, and cracks. | ← |
| | Back-lash between pinion & T.T.B. | | Check the back-lash between the pinion and ring gear of T.T.B. (Standard back-lash ; 0.6 mm (0.02in) or less) |
| | Gear oil. | Check oil level. | Change gear oil. (Oil change interval ; 1,200 hours or Annually) |
| Swivel joint. | Oil leakage. | Apply the maximum pressure, and check for oil leakage. | ← |
| | Anchor bolts, stopper. | Check for looseness. | ← |
| | Slip rings, carbon brushes. | | Remove the cover or carbon brush holder and check for excessive wear, corrosion. |
| | Lubrication. | Supply grease to grease fitting. | ← |
| Control system. | Control levers, switches, cables, linkages. | Test all of the control levers, switches and check the correct function, and any excessive free play. | ← |
| | Instruments. | Check for the function. | ← |
| | Relief valve. | Actuate relief valve, and check for abnormal noise, oil leakage. | Set a pressure gauge, measure the preset pressure of relief valve. |
| | Control valves. | Operate control valves, and check for oil leakage, any other fault. | ← |
| | Name plates, Decals. | Check for legibility and any damage. | ← |
| | Accelerator. | Operate accelerator switch either at lower or upper control and check for the function. | Check accelerator motor, limit switches, cams, wires for any damage. |
| Boom. | Bend, distortion, dent, crack, scratch. | Extend boom fully and check for the items. (The limit of bend ; —Vertically— 0.15% of the boom length. —Horizontally— 0.1% of the boom length.) | ← |
| | Pivot pin. | Check boom pivot pin for excessive wear and any other damage. (The limit of clearance between pin and bushing ; 0.6 mm (0.024in)) | ← |